

only P&H parts
assure P&H performance

FEB 1 1967

Date: _____

Type CRANE

Serial No. _____

Copies of Replacement Parts Manuals are
used for the following:

Purchaser _____

Purchaser's Order No. _____

Shipped To _____

Capacity	<u>20/5 TON</u>	Bridge Type	<u>BR-18</u>	Trolley Type	<u>T-12 - W-12</u>
Span	<u>60' - 0"</u>	Spread	<u>10' - 6"</u>	Lift	<u>30' - 0" 35' - 0"</u>
Girders	<u>Welded Box</u>	Trolley Rail	<u>40</u>	Runway Rail	<u>60</u>
Voltage	<u>550 AC</u>	Phase	<u>3</u>	Cycle	<u>60</u>
Motors	<u>P&H</u>	Controllers	<u>P&H</u>		

BRANCH OFFICE _____

nc: Protective Maintenance of Motors &
Generators (1)

PARTS CATALOG DEPT.

HARNISCHFEGGER

Milwaukee, Wisconsin, U.S.A.

